

ClickClack®

**Now that
you've got me...
here's how
to use me.**

**Equip
Food Processor**

700w motor

2.8L large chopper bowl

INDUCTION
MOTOR

DOUBLE
SAFETY
LOCK

ACCESSORY
STORAGE

24 MONTH (10 YEAR MOTOR)
REPLACEMENT GUARANTEE



FIRSTLY, LET'S STAY SAFE

So I can keep working to your high standards read these safety instructions before using me. They're full of helpful information, so keep them somewhere handy.



Warning

Potential injury from misuse.
Please follow all instructions carefully.

TIPS

Don't try to process any food in me that can't be cut with a sharp knife.

Position the slicing and shredding disks so that their cutting surfaces are to the right of the feed tube. This allows one full rotation of the blade before it contacts the food, which is good!

If you're processing several slices or pieces of food, put as many pieces as will fit in the feed tube together, to help hold each other in place.

Most foods can be processed in 10 to 30 seconds, depending on the quantity. When you're processing large quantities let the processor rest about 1 minute between batches.

If it suddenly stops running, turn OFF and unplug the appliance. Let it cool down for 15 minutes and then restart.

This food processor is NOT designed to grind coffee beans, spices or crush ice.



Important safeguards

READ ALL INSTRUCTIONS BEFORE USE

Warning: Please ensure all safety instructions are followed carefully. Failure to follow instructions could result in personal injury or property damage.

1. Do not use this appliance for anything other than its intended use. This appliance is for household use only.
2. Protective cover fitted on power plug may present as a choking hazard to young children. Remove and discard all packaging before initial use.
3. To protect against the risk of electric shock, do not immerse the Food Processor, power cord or plug in water or any other liquid. Do not handle with wet hands.
4. Do not operate the appliance with a damaged power cord or plug, or if the appliance malfunctions, or if dropped or damaged in any manner. If damage is suspected, contact ClickClick by email or phone. In order to avoid a hazard, repairs and part replacements must be made by a ClickClick authorised service agent only.
5. Turn OFF the appliance and unplug from the power outlet when not in use. Turn OFF the appliance and unplug from the power outlet before: approaching moving parts, assembling or disassembling parts, cleaning, leaving unattended, or storing. To unplug, grasp the power plug and pull from the power outlet. Never pull from the power cord. This appliance is not intended to be operated with an external switching device such as a timer.
6. Keep fingers out of the feed tube and avoid contact with any moving parts. Never feed food by hand or other utensil- always use the food pusher.
7. Blades are very sharp. Be careful when handling the sharp cutting blades, emptying the bowl and during cleaning. Always keep out of reach of children.
8. Keep hands, hair, clothing, and other utensils away from the appliance during operation to reduce the risk of personal injury and/or damage to the appliance. A scraper may be used but only when the appliance is not running.
9. To reduce the risk of injury, never place cutting blades or discs on the base without first ensuring the bowl is properly in place.
10. Ensure the lid is securely locked in place before operating the Food processor. Do not remove the lid while food processor is in operation.
11. Always Ensure the food processor is fully assembled before operation.
12. Do not tamper with the lid interlocking mechanism.
13. Only use the attachments included. The use of attachments not approved or sold by the manufacturer may cause fire, electric shock, or injury.
14. Do not use food processor in moving vehicles. Do not use outdoors or in damp areas.
15. Do not operate the appliance in the presence of flammable materials or fumes, or explosives of any kind.
16. This appliance should not be used by children and care should be taken when used near children. Children should be supervised to ensure that they do not play with the appliance.
17. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety to avoid a hazard.
18. To avoid injury, do not touch any moving parts.
19. Do not use this appliance for processing hot liquids. Always allow liquid and food to cool completely before processing.
20. Keep the appliance away from hot surfaces.
21. Do not let the power cord hang over the edge of a table or bench or come in contact with any hot surfaces including the stove.
22. Ensure the Food processor is placed on a flat dry surface. Do not place the food processor near the edge of the table or bench.
23. Potential injury from misuse.
24. Do not move appliance while in operation
25. Do not leave the appliance unattended when it's turned on and in use.

Specifications

Model: CFP001BK

Rating: 220-240V~ 50Hz 700W

Now it's time to get to know my parts



THE DOUGH BLADE

Use this blade for kneading bread dough and mixing batters and cake mixtures. This blade can take recipes with between 3 to 5 cups of flour.

Most dough and batters will take between 1 - 3 minutes to process.

THE S BLADES

These are your multipurpose blades! Use them for chopping, mixing, blending, pureeing, mincing, making pastry and crumbing.

Put your ingredients in the bowl, fasten the lid onto the bowl and put the pusher in the feed tube. You're good to go!

If you're chopping, mincing or pureeing, it's best to cut the food into 1" to 1 1/2" pieces and process them in batches.

These are the maximum quantities you should have in the bowl at one time:

Meat 250g

Fruits and Vegetables 500g

Hard Cheeses (like Parmesan) 250g

Soft Cheeses (like Cheddar) 250g

If you're mincing garlic, fresh herbs or small quantities, just add the food to the feed tube with the motor running. It's best to make sure my bowl and all my parts are very dry before you start.

You can use the pulse feature to prevent over-processing.

Most foods should take 10 to 30 seconds to process. You should avoid letting the food processor run continuously. It's not good for the engine!

If food sticks to the blade or the side of bowl while processing, just turn the appliance off, remove the lid, and use a spatula to move the food around.



THE SLICING AND SHREDDING DISKS

These slice and shred meat, fruit, vegetables, cheeses and more.

Put your ingredients in the feed tube and press the pusher **LIGHTLY AND STEADILY** onto the ingredients. Don't press it too hard - it might damage the disk.

Remember: Always pre-cut large chunks of food to fit the size of the feed tube and fill the feed tube evenly.

It's good to make sure uncooked meats and poultry are very cold before processing.

And if you're processing large quantities, process small batches at a time. Slow and steady wins the race!



FRENCH FRIES CUTTING DISK

Cut your own French fries perfectly!

Just put your ingredients in the feed tube and press the pusher lightly and steadily onto the ingredients.



CHEESE GRATING DISK

Put your cheese in the feed tube and press the food pusher lightly onto the ingredients.

Let hard cheeses like Parmesan and Romano come to room temperature before you process them.

For soft cheeses like cheddar and mozzarella, it helps to freeze them for 10 to 15 minutes before you process them.



11
FRENCH FRIES
CUTTING DISK



12
CHEESE
GRATING DISK



13
SHREDDING
DISK



14
SLICING
DISK

Chopper attachment:
S- Blade - Fish cake/ 800g fish (20 sec) + [760g flour & 540ml water] (40 sec)

Cleaning

CAUTION – BEFORE YOU GET STARTED:

- **Unpack all the parts and remove all of the packaging materials carefully. (Please recycle packaging if possible).**
- **Wash all the parts. (But don't put the motor unit, cord or plug in water! Just wipe these parts with a damp cloth).**
- **Be careful not to use abrasive cleaners or scouring pads on the bowl or lid. These might scratch or damage the food processor.**
- **And be extra careful of the blades and cutting plates. They are super sharp!**
- **Dry thoroughly. Never immerse the motor unit, power cord or plug in water or any other liquid!**

Usage Instructions

Clean before initial use – refer to cleaning instructions above.

CAUTION:

- **Make sure the food processor is turned off and unplugged.**
- **Turn the lid on the bowl clockwise and remove.**
- **If you've been using a slicing or shredding disk remove the disk before you remove the bowl. Just put two fingers through the holes in the disk and lift the disk straight up. Watch out for those sharp blades!**
- **Turn the bowl clockwise to unlock it from the motor unit. Lift it up to remove it.**
- **To clean the appliance, wash the bowl, lid and attachments in warm, soapy water. Wipe the motor unit with a clean, damp cloth. Dry thoroughly. Never immerse the motor unit, power cord or plug in water or any other liquid!**
- **Dry thoroughly. Never immerse the motor unit, power cord or plug in water or any other liquid!**
- **Store the bowl and lid in the unlocked position when you're not using the food processor. And store all the accessories in a safe place out of reach of little children.**

Let's get processing!

1. Place the motor unit on a dry, level surface. Don't plug the appliance in until it is fully assembled.
2. Put the bowl on top of the motor unit, with the handle just to the left of center. Then turn the bowl counter-clockwise until the bowl clicks into place.
3. Select the attachment you want to use and position it onto the drive shaft. If it's a disk, put the disk post onto the drive shaft first and turn the post counter-clockwise to lock it into place. Then carefully attach the disk onto the disk post.
4. Place your food in the bowl (or down the feed tube), put the lid on and turn it counter-clockwise until it clicks into place. (The food processor won't work unless the bowl and lid are fitted properly and locked into place).
5. Plug the appliance into a 230VAC 50Hz outlet only. Turn the food processor on by pressing the ON button. You're good to go!
6. Press the ON button to start the processing, press the OFF button to stop. Make sure you wait until the food processor has come to a complete stop before removing the lid!

